

ATTENZIONE - ATTENTION - ACHTUNG

- Per lo smontaggio degli utensili utilizzare sempre la chiave di contrasto come indicato nel manuale d'uso.
- For disassembly of the tools use always the contrast key as mentioned in the user instructions.
- Fuer das Abmontieren der Werkzeuge immer den Gegenschlüssel benutzen wie in der Bedienungsanleitung erwäehnt.

- Chiave inclusa
- Key included
- Schluessel inbegriffen


Cod. MT	Mandrino Spindle Spindel	I	RPM	Coppia Max Max Torque Max Drehmoment	N°Utensili N° Tools N° Werkzeuge	Reversibile lato mandrino/contromandrino Reversible sub/main spindle side Umkehrbare Spindel-seite/ Gegenspindel-seite	Lubr.interna Coolant through Innenkuehlung	Lubr.esterna Ext. coolant Aussenkuehlung	A	B	CHIAVI NON INCLUDE Keys not included Schluessel nicht einbegriffen		
											CHUB36	CHSTER25	-
MNL0220225	ER25	1:1	6000	40Nm	2	X	-	X	137.96	68	CHUB36	CHSTER25	-
MNL0221225	ER25	1:1	6000	40Nm	2	X	P=70bar	X	162.66	68	CHUB36	CHSTER25	-
MNL0220325	ERA25	1:1	6000	40Nm	2	X	-	X	126.5	68	CHUB38	CHUB27	CHTAER25ZC *
MNL0221325	ERA25	1:1	6000	40Nm	2	X	P=70bar	X	156.03	68	CHUB38	CHUB27	-
MNL1250225	ER25+ER25	1:1	6000	40Nm	2+2	X	-	X	137.96	137.96	CHUB36	CHSTER25	-
MNL1250325	ERA25+ERA25	1:1	6000	40Nm	2+2	X	-	X	126.5	126.5	CHUB38	CHUB27	CHTAER25ZC *

DMG-MORI

NL1500/2000/2500/3000 12 STAZIONI - NLX1500/2000/2500/3000 12 STAZIONI - NLX4000 - NZL2000/2500 - NZX2500 (BMT60)
NT4200/4250/4300/5400 - NTX2000/2500/3000 2ND GEN. 10ST. - CTX2500 (BMT60)

MODULO MOTORIZZATO ASSIALE 2 USCITE IN Y
Axial Single side twin head driven tool in Y
Axial angetriebenes Werkzeug 2 Ausgaenge in Y

Subject to change without notice.



M.T. srl

Via Casino Albini 480
Tel. 0541/956034-957884
Fax 0541/956341
47842 S. GIOVANNI IN M. (RN)
e-mail: mtma@mtmarchetti.com
http://www.mtmarchetti.com



MNL260-1-10